


6716HB ASSEMBLY INSTRUCTIONS





Insert Glides (H) or Casters (I) into each of the 5 legs (A).

Insert column (C) firmly into the center of leg base.

STEP 2

Align seat mounting plate/backrest arm (B) with screw holes in underside of seat (D).

Loosely insert 4 seat bolts (G) through holes on seat mount plate (B) into the holes on the underside of seat (D), and <u>only tighten slightly</u> using the included allen key.

Once all 4 bolts (G) are properly inserted, tightly secure them in a crossed fashion.



Once seat mounting plate/backrest arm (B) has been installed to seat (D), place seat (D) over upper potion of column (C) and push down firmly.



Place Backrest Bracket (F) onto the outer side of backrest arms (B) top plate. Then place the Backrest (E) in front of top plate.

Align the holes on the Backrest (E), Backrest Arm (B), Bracket (F) and use the 2 bolts (G) to tightly secure them together.