

# **National Public SEATING Corp.**

---

Thank you for your purchase of the TPA fourth-level add-on for our Transport Choral Riser. Please note that this unit is not recommended to be used as a stand-alone unit. It should be used as an add-on to the Transport riser and should be securely connected to the unit by following the below instructions:

#### Hardware included:

4 sets of ganging clamps

4 bolts

4 wing nuts

4 lock nuts

#### Unit Set-Up

1. Remove unit from carton and open both legs assuring that they are completely open and are in the locked position.
2. Place and align unit at the back of the Transport Riser.

#### Attaching unit to Riser

1. Begin towards the bottom of legs by placing sleeves of clamp with welded bolt onto the inside of leg of the riser and TPA with bolt facing the outside. Assure that the hole on the sleeve aligns with the hole on the leg of the TPA. See ILL. A.
2. Place the second half of clamp onto the first half allowing the welded bolt to go through the hole on second clamp.
3. Use a wing nut to tighten clamps. See ILL B.
4. Insert a bolt through the hole in the sleeve of clamp and push through unit leg. Tighten with lock nut. See ILL. C.
5. Use the second set of clamps and place above cross-brace on legs of the unit.
6. Follow the above steps for the other side of unit.

